

To sheet / Vers la page / Al foglio / Zu Blatt / Naar pagina: _____

Panel Group / Groupe de modules / Gruppo di moduli / Modulgruppe / Modulegroep: Azimuth / Azimut: Tilt / Inclinaison / Inclinazione / Neigungswinkel / Helling: sheet / page / foglio / Blatt / pagina _____ / _____			Client / Cliente / Kunde / Cliënt:		Installer / Installateur / Installatore:		N S E W / N S E O N S O W / N Z O W
	1	2	3	4	5	6	7
A							
B							
C							
D							
E							
F							
G							
H							
J							
K							

To sheet / Vers la page / Al foglio / Zu Blatt / Naar pagina: _____

Envoy serial label /
étiquette de numéro de série /
etichette di serie Envoy /
Serien Nummer / Label seriennummer:

To sheet / Vers la page / Al foglio / Zu Blatt / Naar pagina: _____



INSTALLATION MAP / PLAN D'INSTALLATION
MAPPA INSTALLAZIONE / INSTALLATIONSPLAN
INSTALLATIE KAART

ENPHASE.COM

© 2018 Enphase Energy Inc. All rights reserved.

Install the Enphase IQ 7A Microinverter

To install Enphase IQ Series Microinverters, read and follow all warnings and instructions in this guide and in the *Enphase IQ 7A Microinverter Installation and Operation Manual* at enphase.com/support. Safety warnings are listed on the back page of this guide.

The Enphase Microinverter models listed in this guide do not require grounding electrode conductors (GEC) or equipment grounding conductors (EGC). The microinverter has a Class II double-insulated rating, which includes ground fault protection (GFP). To support GFP, use only PV modules equipped with DC cables labeled **PV Wire** or **PV Cable**.

IMPORTANT: Enphase IQ Series Microinverters require the Q Cable and are not compatible with previous Enphase cabling. An Envoy-S is required to monitor performance of the IQ Microinverters. The Q Accessories work only with Enphase IQ Series Microinverters.

PREPARATION

- A) Download the Enphase Installer Toolkit mobile app and open it to log in to your Enlighten account. With this app, you can scan microinverter serial numbers and connect to the Enphase Envoy-S to track system installation progress. To download, go to enphase.com/toolkit or scan the QR code at right.
- B) Refer to the following table and check PV module compatibility at: enphase.com/en-us/support/module-compatibility.
- D) Check that you have these other items:
- An AC junction box or AC isolator.
 - Tools: screwdrivers, wire cutter, voltmeter, torque wrench, sockets, and wrenches for mounting hardware
 - Field Wireable Connectors (Q-CONN-R-10M and Q-CONN-R-10F for single phase Q Cable or Q-CONN-3P-10M and Q-CONN-3P-10F for multiphase Q Cable): optional male and female connectors for single phase connections.



Model	DC connector	PV module cell count
IQ7A-72-2-INT	MC4 type, locking	Pair with 60 cell /120-half-cell or 72 cell / 144-half-cell

- C) In addition to the Enphase Microinverters, PV modules and racking, you will need these Enphase items:
- An Enphase Envoy-S (model ENV-S-WM-230 or ENV-S-WB-230-F/G/I) communications gateway is required to monitor solar production and may be required to propagate a grid profile to the microinverters.
- E) Protect your system with lightning and/or surge suppression devices. It is also important to have insurance that protects against lightning and electrical surges.
- F) Plan your AC branch circuits to meet the following limits for maximum number of microinverters per branch when protected with a 20-amp over-current protection device (OCPD) . For multiphase installations, use a 3-pole 25A OCPD.

Maximum* IQ 7A Micros per AC branch circuit	
Single-phase	11 (20 A OCPD)
Multiphase	39 (25 A OCPD)



* Limits may vary. Refer to local requirements to define the number of microinverters per branch in your area.

- G) Size the AC wire gauge to account for voltage rise. Select the correct wire size based on the distance from the beginning of the Enphase Q Cable to the breaker in the load center. Refer to the Voltage Rise Technical Brief at enphase.com/support for details.

Best practice: Parallel centre-feed the branch within the circuit to minimise voltage rise in a fully-populated branch.

Cable model	Connector spacing*	PV module orientation	Connectors per box
Single-phase			
Q-25-10-240	1.3m	Portrait (all)	240
Q-25-17-240	2.0m	Landscape (60- and 96-cell)	240
Q-25-20-200	2.3m	Landscape (72-cell)	200
Multiphase			
Q-25-10-3P-200	1.3m	Portrait (all)	200
Q-25-17-3P-160	2.0m	Landscape (60- and 96-cell)	160
Q-25-20-3P-160	2.3m	Landscape (72-cell)	160

*Allows for 30 cm of cable slack.



148-08161-01

INSTALLATION

1 Position the Enphase Q Cable

- Plan each cable segment to allow connectors on the Enphase Q Cable to align with each PV module. Allow extra length for slack, cable turns, and any obstructions.
- Mark the approximate centers of each PV module on the PV racking.
- Lay out the cabling along the installed racking for the AC branch circuit.
- Cut each segment of cable to meet your planned needs.



2 Position the Junction Box/AC Isolator

- Verify that AC voltage at the site is within range:

Single-Phase Service	Three-Phase Service
L1 to N	207 to 253 VAC
	L1 to L2 to L3
	360 to 440 VAC
	L1, L2, L3 to N
	207 to 253 VAC

- Install a junction box/AC isolator at a suitable location on the racking.
- Provide an AC connection from the junction box/AC isolator back to the electricity network connection using equipment and practices as required by local jurisdictions.


3 Mount the Microinverters

- Mount the microinverter bracket side up (as shown) and under the PV module, away from rain and sun.** Allow a minimum of 1.9 cm between the roof and the microinverter. Also allow 1.3 cm between the back of the PV module and the top of the microinverter.



- Torque the mounting fasteners as follows. Do not over torque.


- 6 mm mounting hardware: 5 N m
- 8 mm mounting hardware: 9 N m
- When using mounting hardware, use the manufacturer's recommended torque value



4 Create an Installation Map

Create a paper installation map to record microinverter serial numbers and position in the array.


- Peel the removable serial number label from each microinverter and affix it to the respective location on the paper installation map.
- Peel the label from the Envoy-S and affix it to the installation map.
- Always keep a copy of the installation map for your records.



Affix serial number labels




5 Manage the Cabling

- Use cable clips or tie wraps to attach the cable to the racking. The cable must be supported at least every 300 mm.
- Dress any excess cabling in loops so that it does not contact the roof. Do not form loops smaller than 12 cm in diameter.



6 Connect the Microinverters









- Connect the microinverter. Listen for a click as the connectors engage.
- Cover any unused connectors on the AC cable with Enphase Sealing Caps. Listen for a click as the sealing caps engage.




To remove a sealing cap or AC connector, you must use an Enphase disconnect tool.



7 Terminate the Unused End of the Cable

Single-phase Q Cable	Three-phase Q Cable
A) Remove 13 mm of the cable sheath from the conductors. Use the terminator body loop to measure. 	A) Remove 20 mm of the cable sheath from the conductors. 
B) Slide the hex nut onto the cable. The grommet inside the terminator body must remain in place. 	B) Slide the hex nut onto the cable. The grommet inside the terminator body must remain in place. 
C) Insert the cable into the terminator body so that the two wires land on opposite sides of the internal separator. 	C) Insert the cable into the terminator body so that the four wires land on separate sides of the internal separator. 
D) Insert a screwdriver into the slot on the top of the terminator to hold it in place. Hold the terminator body stationary with the screwdriver and turn only the hex nut to prevent the conductors from twisting out of the separator. Torque the nut to 7.0 Nm. 	D) Bend the wires down into the recesses of the terminator body and trim as needed. Place the cap over the terminator body. Insert a screwdriver into the slot on the terminator cap to hold it in place. Rotate the hex nut with your hand or a wrench until the latching mechanism meets the base. Do not over torque. 
E) Attach the terminated cable end to the PV racking with a cable clip or tie wrap so that the cable and terminator do not touch the roof.	E) Attach the terminated cable end to the PV racking with a cable clip or tie wrap so that the cable and terminator do not touch the roof.




8 Complete Installation of the Junction Box/AC Isolator

- Connect the Enphase Q Cable into the junction box/AC isolator.
- Note that the Q Cable uses the following wiring colour code:

Single-Phase	Three-Phase
Brown – L1 active Blue - Neutral	Brown – L1 active Black – L2 active Grey – L3 active Blue - Neutral

NOTE: The Q Cable internally rotates L1, L2, and L3 to provide balanced 400 VAC (three-phase), thus alternating phases between microinverters.


NOTE: Minimise the number of unused Q Cable connectors with three-phase systems. When cable connectors are left unused on a three-phase system, it creates a phase imbalance on the branch circuit. If multiple cable connectors are skipped over multiple branch circuits, the imbalance can multiply.



9 Connect the PV Modules



- Connect the DC leads of each PV module to the DC input connectors of the microinverter.
- Check the LED on the connector side of the microinverter. The LED flashes six times when DC power is applied.
- Mount the PV modules above the microinverters.



10 Energise the System

- Turn ON the AC disconnect or circuit breaker for the branch circuit.
- Turn ON the main utility-grid AC circuit breaker. Your system will ramp up to full producing power **after a six-minute wait time.**
- Check the LED on the connector side of the microinverter:

LED	Indicates
Flashing green	Normal operation. AC grid function is normal and there is communication with the Envoy-S.
Flashing orange	The AC grid is normal but there is no communication with the Envoy-S.
Flashing red	The AC grid is either not present or not within specification.
Solid red	There is an active "DC Resistance Low, Power Off" condition. To reset, refer to the <i>Enphase Envoy-S Installation and Operation Manual</i> at: http://www.enphase.com/support .

ACTIVATE MONITORING AND SELECT GRID PROFILE





After you have installed the microinverters, follow the procedures in the *Enphase Envoy-S Quick Install Guide* to activate system monitoring, set up grid management functions, and complete the installation.













- Connect the Envoy-S
- Detect devices and select grid profile
- Connect to Enlighten
- Register the system
- Build the virtual array








SAFETY










IMPORTANT SAFETY INSTRUCTIONS
SAVE THIS INFORMATION. This guide contains important instructions to follow during installation of the Enphase IQ7A Microinverters.











	WARNING: Hot surface.
	WARNING: Refer to safety instructions.
	DANGER: Risk of electric shock.
	Refer to manual
	Double-Insulated

Safety Symbols	
	DANGER: Indicates a hazardous situation, which if not avoided, will result in death or serious injury.
	WARNING: Indicates a situation where failure to follow instructions may be a safety hazard or cause equipment malfunction. Use extreme caution and follow instructions carefully.
	WARNING: Indicates a situation where failure to follow instructions may result in burn injury.
	NOTE: Indicates information particularly important for optimal system operation.

General Safety	
	DANGER: Risk of electric shock. Do not use Enphase equipment in a manner not specified by the manufacturer. Doing so may cause death or injury to persons, or damage to equipment.
	DANGER: Risk of electric shock. Be aware that installation of this equipment includes risk of electric shock.
	DANGER: Risk of electric shock. The DC conductors of this photovoltaic system are ungrounded and may be energised.
	DANGER: Risk of electric shock. Always de-energise the AC branch circuit before servicing. Never disconnect the DC connectors under load.
	DANGER: Risk of electric shock. Risk of fire. Only use electrical system components approved for wet locations.
	DANGER: Risk of electric shock. Risk of fire. Only qualified personnel should troubleshoot, install, or replace Enphase Microinverters or the Enphase Q Cable and Accessories.
	DANGER: Risk of electric shock. Risk of fire. Ensure that all AC and DC wiring is correct and that none of the AC or DC wires are pinched or damaged. Ensure that all AC junction boxes are properly closed.
	DANGER: Risk of electric shock. Risk of fire. Do not exceed the maximum number of microinverters in an AC branch circuit as listed in this guide. You must protect each microinverter AC branch circuit with a 20A (single phase) or 25A (three phase) maximum breaker or fuse, as appropriate.
	DANGER: Risk of electric shock. Risk of fire. Only qualified personnel may connect the Enphase Microinverter to the utility grid.
	WARNING: Risk of equipment damage. Enphase male and female connectors must only be mated with the matching male/female connector.
	WARNING: Before installing or using the Enphase Microinverter, read all instructions and cautionary markings in the technical description, on the Enphase Microinverter System, and on the photovoltaic (PV) equipment.
	WARNING: Do not connect Enphase Microinverters to the grid or energise the AC circuit(s) until you have completed all of the installation procedures and have received prior approval from the electrical utility company.

General Safety, continued	
	WARNING: When the PV array is exposed to light, DC voltage is supplied to the PCE.
	WARNING: Incorrect phase wiring can cause irreversible damage to the microinverter installation. Check all wiring before energising.
	NOTE: To ensure optimal reliability and to meet warranty requirements, install the Enphase Microinverters and Enphase Q Cable according to the instructions in this guide.
	NOTE: Provide support for the Enphase Q Cable at least every 300 mm.
	NOTE: Perform all electrical installations in accordance with all applicable local electrical codes.
	NOTE: The AC and DC connectors on the cabling are rated as a disconnect only when used with an Enphase Microinverter.
	NOTE: Protection against lightning and resulting voltage surge must be in accordance with local standards.

Microinverter Safety	
	DANGER: Risk of electric shock. Risk of fire. Do not attempt to repair the Enphase Microinverter; it contains no user-serviceable parts. If it fails, contact Enphase customer service to obtain an RMA (return merchandise authorisation) number and start the replacement process. Tampering with or opening the Enphase Microinverter will void the warranty.
	DANGER: Risk of fire. The DC conductors of the PV module must be labeled "PV Wire" or "PV Cable" when paired with the Enphase Microinverter.
	WARNING: You must match the DC operating voltage range of the PV module with the allowable input voltage range of the Enphase Microinverter.
	WARNING: The maximum open circuit voltage of the PV module must not exceed the specified maximum input DC voltage of the Enphase Microinverter.
	WARNING: Risk of equipment damage. Install the microinverter under the PV module to avoid direct exposure to rain, UV, and other harmful weather events. Always install the microinverter bracket side up. Do not mount the microinverter upside down. Do not expose the AC or DC connectors (on the Enphase Q Cable connection, PV module, or the microinverter) to rain or condensation before mating the connectors.
	WARNING: Risk of equipment damage. The Enphase Microinverter is not protected from damage due to moisture trapped in cabling systems. Never mate microinverters to cables that have been left disconnected and exposed to wet conditions. This voids the Enphase warranty.
	WARNING: Risk of equipment damage. The Enphase Microinverter functions only with a standard, compatible PV module with appropriate fill-factor, voltage, and current ratings. Unsupported devices include smart PV modules, fuel cells, wind or water turbines, DC generators, and non-Enphase batteries, etc. These devices do not behave like standard PV modules, so operation and compliance is not guaranteed. These devices may also damage the Enphase Microinverter by exceeding its electrical rating, making the system potentially unsafe.
	WARNING: Risk of skin burn. The chassis of the Enphase Microinverter is the heat sink. Under normal operating conditions, the temperature could be 20°C above ambient, but under extreme conditions the microinverter can reach a temperature of 90°C. To reduce risk of burns, use caution when working with microinverters.
	NOTE: The Enphase Microinverter has field-adjustable voltage and frequency trip points that may need to be set, depending upon local requirements. Only an authorised installer with the permission and following requirements of the local electrical authorities should make adjustments.

Enphase Q Cable Safety	
	DANGER: Risk of electric shock. Do not install the Enphase Q Cable terminator while power is connected.
	DANGER: Risk of electric shock. Risk of fire. When stripping the sheath from the Enphase Q Cable, make sure the conductors are not damaged. If the exposed wires are damaged, the system may not function properly.
	DANGER: Risk of electric shock. Risk of fire. Do not leave AC connectors on the Enphase Q Cable uncovered for an extended period. You must cover any unused connector with a sealing cap.
	DANGER: Risk of electric shock. Risk of fire. Make sure protective sealing caps have been installed on all unused AC connectors. Unused AC connectors are live when the system is energised.
	WARNING: Use the terminator only once. If you open the terminator following installation, the latching mechanism is destroyed. Do not reuse the terminator. If the latching mechanism is defective, do not use the terminator. Do not circumvent or manipulate the latching mechanism.
	WARNING: When installing the Enphase Q Cable, secure any loose cable to minimise tripping hazard.
	NOTE: The Enphase Microinverter models listed in this guide do not require grounding electrode conductors (GEC), equipment grounding conductors (EGC), or grounded conductor (neutral). The microinverter has a class II double-insulated rating, which includes ground fault protection (GFP). To support GFP use only PV modules equipped with DC cables labeled PV Wire or PV Cable.
	NOTE: When looping the Enphase Q Cable, do not form loops smaller than 12 cm in diameter.
	NOTE: If you need to remove a sealing cap, you must use the Enphase disconnect tool.
	NOTE: When installing the Enphase Q Cable and accessories, adhere to the following: <ul style="list-style-type: none">• Do not expose the terminator or cable connections to directed, pressurised liquid (water jets, etc.).• Do not expose the terminator or cable connections to continuous immersion.• Do not expose the terminator or cable connections to continuous tension (e.g., tension due to pulling or bending the cable near the connection).• Use only the connectors and cables provided.• Do not allow contamination or debris in the connectors.• Use the terminator and cable connections only when all parts are present and intact.• Do not install or use in potentially explosive environments.• Do not allow the terminator to come into contact with open flame.• Fit the terminator using only the prescribed tools and in the prescribed manner.• Use the terminator to seal the conductor end of the Enphase Q Cable; no other method is allowed.