

Install Enphase IQ 8D Microinverters

To install Enphase IQ 8D Microinverters, read and follow all warnings and instructions in this guide and in the *Enphase IQ 8D Microinverter Installation and Operation Manual* at: enphase.com/support. Each IQ 8D Microinverter supports two series-connected PV modules, and is a small commercial solution for grid-tied, three-phase, 208 V PV applications. Safety warnings are listed on the back page of this guide.

The Enphase Microinverter models listed in this guide do not require grounding electrode conductors (GEC), equipment grounding conductors (EGC), or grounded conductor (neutral). The microinverter has a Class II double-insulated rating, which includes ground fault protection (GFP). To support GFP, use only PV modules equipped with DC cables labeled **PV Wire** or **PV Cable**.

IMPORTANT: The Enphase IQ Series EN4 Bulkhead Microinverters include AC and DC connectors integrated into the microinverter bulkhead. The AC port of the Enphase EN4 bulkhead connects to an Enphase QD Cable. The DC port of the EN4 Bulkhead has been evaluated by UL for intermatability with TE PV4-S SOLARLOK connectors. See models under PREPARATION.

PREPARATION

A) Download the Enphase Installer Toolkit mobile app and open it to log in to your Enlighten account. With this app, you can scan microinverter serial numbers and connect to the Enphase IQ Envoy to track system installation progress. To download, go to enphase.com/toolkit or scan the QR code at right.



B) Refer to the following table and check PV module electrical compatibility at: enphase.com/en-us/support/module-compatibility.

Model	DC connector	PV module cell count
IQ8D-72-E-US	EN4 locking	Pair with two series-connected 60- or 72-cell modules

C) In addition to the Enphase Microinverters, PV modules and racking, you will need these **Enphase items**:

- Enphase IQ Commercial Envoy™ (model ENV-IQ-AM3-3P): required to monitor solar production.
- Enphase Mobile Connect™ (model CELLMODEM-M1) 4G-based LTE-M modem. Contact Enphase for data plan options.
- If your PV modules have TE PV4S SOLARLOK connectors, or other connectors Listed and identified for intermatability with the Enphase EN4 bulkhead connector, you may plug them directly into the IQ 8D microinverter with EN4 bulkhead. An Enphase bulkhead adapter (pair of ECA-EN4-S22) is provided with the IQ8D. For other connections, the following Enphase bulkhead adapter options are available.

Adapter ¹	Part number	Model SKU
EN4 (TE PV4-S SOLARLOK) 150mm/5.9" to MC4 ²	860-00311	ECA-EN4-S22
EN4 (TE PV4-S SOLARLOK) to 150mm/5.9" non-terminated cable ³	860-00312	ECA-EN4-FW
EN4 (TE PV4-S SOLARLOK) 600mm/23.6" to MC4 ²	860-00315	ECA-EN4-S22-L

1. All adapters rating for disconnect under load: Max. 119 VDC
 2. Qualified per UL subject 9703.
 3. For field wiring of UL certified DC connectors.

- Tie wraps or cable clips (Q-CLIP-100)
- Enphase Sealing Caps (QD-SEAL-10): for any unused connectors on the Enphase QD Cable
- Enphase Terminator (QD-TERM-10): one needed at the end of each AC cable segment
- Enphase link field wireable adapter cable (QD-LINKFW-10)
- Enphase three-phase field wireable connectors (QD-CONN-10M and QD-CONN-10F)
- Enphase disconnect tool (QD-DISC-10)

Enphase QD cable (as listed in the following table):


Cable model SKU	Connector spacing	PV module orientation	Connectors per box
QD-12-10-150	1.4m	Portrait	150
QD-12-20-135	2.4m	Landscape	135
QD-12-42-63	4.6m	Landscape ballast, east-west mount structure	63

D) Field wireable connectors are pre-installed at the ends of the QD cables to increase the cable length beyond the connector limit mentioned in above table. The field wireable connectors are protected with sealing caps. The sealing caps must be removed when you are increasing cable length using the field wireables at the cable end.

Warning: Do not remove sealing caps from the cable end field wireable connectors if they are not used to increase cable length.

- E) Check that you have these other items:
 - AC junction box.
 - Tools: screwdrivers, wire cutter, voltmeter, torque wrench, sockets, and wrenches for mounting hardware
- F) Protect your system with lightning / surge suppression devices. It is also important to have insurance that protects against lightning / electrical surges.
- G) Plan your AC branch circuits to meet the following limits for maximum number of microinverters per three-phase branch when protected with a 20-amp over-current protection device (OCPD).
 - Nine IQ 8D microinverters maximum* per 20 A 208 V AC (L-L), 3P branch (20 A X 0.8 X 1.732 / 3.04 A)
 - * Limits may vary. Refer to local requirements to define the number of microinverters per branch in your area.
- H) Size the AC wire gauge to account for voltage rise. Select the correct wire size based on the distance from the beginning of the Enphase QD Cable to the breaker in the load center. Design for a voltage rise total of less than 2% for these sections. Refer to the Voltage Rise Technical Brief at enphase.com/support for more information.

Best practice: Center-feed the branch circuit to minimize voltage rise in a fully-populated branch.



148-88191-81

INSTALLATION

1 Position the Enphase QD Cable

- A) Plan each cable segment to allow connectors on the Enphase QD Cable to align with each PV module. Allow extra length for slack, cable turns, and any obstructions.
- B) Mark the approximate centers of each PV module on the PV racking.
- C) Lay out the cabling along the installed racking for the AC branch circuit.
- D) Cut each segment of cable to meet your planned needs.



WARNING: When transitioning between rows, secure the cable to the rail to prevent cable or connector damage. Do not count on the connector to withstand tension.

2 Provide an AC Connection to Branch Circuit

Method A: Center-feeding the branch circuit


It is a best practice to center-feed the AC supply to the microinverter branch circuit to limit voltage rise to less than 2% for the site. Center-feeding is **recommended** for all installations with the QD-12-42-63 QD Cable.

- A) The QD-12-42-63 cable includes a center-tapping connector in an alternating pattern after sequences four and five connectors.



WARNING: The center-tapping AC male connector is marked "Center tap; Not for microinverter connection". Do not use the center tap connectors for connecting to the microinverter.

- B) Plan and install the system so that a maximum of six microinverters are installed on either side of a center-tapping connector.
- C) Use a link field wireable adapter (QD-LINKFW-10) to connect the center-tapping connector to the home run cable using a female three-phase field wireable connector (QD-CONN-10F).



Method B: End-feeding the branch circuit

- A) You can end feed the AC supply to the microinverter branch circuit using QD cable SKUs QD-12-10-150 and QD-12-20-135.
- B) Use three-phase field wireable connectors or an AC junction box to provide the AC connection to the microinverter branch circuit.

All methods: Complete the AC connection

- A) Provide an AC connection from the three-phase field wireable connectors or AC junction box back to the electricity network connection using equipment and practices as required by local jurisdictions.
- B) Verify that AC voltage at the site is within range:

Service type and voltage: L1-L2, L2-L3 and L3-L1	
208 VAC three-phase	183 to 229 VAC


3 Mount the Microinverters

- A) **Mount the microinverter bracket side up (as shown) and under the PV module, away from rain and sun.** Allow a minimum of 1.9 cm (0.75 inches) between the roof and the microinverter. Also allow 1.3 cm (0.50 inches) between the back of the PV module and the top of the microinverter.



WARNING: Install the microinverter under the PV module to avoid direct exposure to rain, UV, and other harmful weather events. Do not mount the microinverter upside down.


- B) Torque the mounting fasteners (1/4-inch or 5/16-inch) as follows. Do not over torque.
 - 6 mm (1/4 inches) mounting hardware: 5 N m (45 to 50 in-lbs)
 - 8 mm (5/16 inches) mounting hardware: 9 N m (80 to 85 in-lbs)
 - When using UL 2703 mounting hardware, use the manufacturer's recommended torque value



4 Create an Installation Map

Create a paper installation map to record microinverter serial numbers and position in the array.


- A) Peel the removable serial number label from each microinverter and affix it to the respective location on the paper installation map.
- B) Peel the label from the IQ Envoy and affix it to the installation map.
- C) Always keep a copy of the installation map for your records.



Affix serial number labels

5 Manage the Cabling


- A) Use cable clips or tie wraps to attach the cable to the racking. The cable must be supported at least every 1.8 m (6 feet).
- B) Dress any excess cabling in loops so that it does not contact the roof. Do not form loops smaller than 12 cm (4.75 inches) in diameter.



Cable clip

6 Connect the Microinverters

- Connect the microinverter to the QD Cable. Listen for a click as the connectors engage.
- Cover any unused connectors on the AC cable with Enphase Sealing Caps. Listen for a click as the sealing caps engage.




WARNING: Install sealing caps on all unused AC connectors as these connectors become live when the system is energized. Sealing caps are required for protection against moisture ingress.


To remove a sealing cap or AC connector, you must use an Enphase disconnect tool.

7 Terminate the Unused End of the Cable

- Remove 20 mm (0.8 inches) of the cable sheath from the conductors.



- Slide the hex nut onto the cable. The grommet inside the terminator body must remain in place.



- Insert the cable into the terminator body so that the four wires land on separate sides of the internal separator.



- To attach the cap:
 - Bend the wires down into the recesses of the terminator body and trim as needed. Place the cap over the terminator body.
 - Insert a screwdriver into the slot on the terminator cap to hold it in place.
 - Rotate the hex nut with your hand or a wrench until the latching mechanism meets the base.
 - Do not over torque.



- Attach the terminated cable end to the PV racking with a cable clip or tie wrap so that the cable and terminator do not touch the roof.



WARNING: The terminator can not be re-used. If you unscrew the nut, you must discard the terminator.

8 Connect the Series-Connected PV Modules




DANGER! Electric shock hazard. The DC conductors of this PV system are ungrounded and may be energized.

- Series connect two compatible PV modules per manufacturer instructions. **Do not skip this step.**
- If required, attach the Enphase DC bulkhead adapters to the microinverters. Make sure they are fully seated. **Do not reverse the adapter connections.**
- Connect the DC leads of each PV module to the DC input connectors or adapters of the microinverter.
- Check the LED on the connector side of the microinverter. The LED flashes six times when DC power is applied.
- Mount the PV modules above the microinverters.

DC connectors

Adapters (if required)

Status LED



WARNING: If adapters are used, ensure they are installed in the correct orientation.

9 Energize the System

- Turn ON the AC disconnect or circuit breaker for the branch circuit.
- Turn ON the main utility-grid AC circuit breaker. Your system will start producing power **after a five-minute wait time.**
- Check the LED on the connector side of the microinverter:

LED	Indicates
Flashing green	Normal operation. AC grid function is normal and there is communication with the IQ Envoy
Flashing orange	The AC grid is normal but there is no communication with the IQ Envoy
Flashing red	The AC grid is either not present or not within specification
Solid red	There is an active "DC Resistance Low, Power Off" condition. To reset, refer to the <i>Enphase IQ Envoy Installation and Operation Manual</i> at: http://www.enphase.com/support .

ACTIVATE MONITORING AND CONTROLS

After you have installed the microinverters, follow the procedures in the *Enphase IQ 8D Envoy Quick Install Guide* to activate system monitoring, set up grid management functions, and complete the installation.

- Connecting the IQ 8D Commercial Envoy and detecting devices
- Connecting to Enlighten, registering the system, and building the virtual array

Enphase Connector Rating: Enphase connectors on the assemblies in the following table have a maximum current of 20 A, a maximum OCPD of 20 A, and maximum ambient temperature of -40° to +79° C (-40° to +174.2° F) and are rated for disconnection under load.

Part Number	Model	Maximum Voltage
840-00730	QD-12-10-150	250 VAC
840-00731	QD-12-20-135	250 VAC
840-00732	QD-12-42-63	250 VDC
860-00311	ECA-EN4-S22	80 VDC
860-00315	ECA-EN4-S22-L	80 VDC

PV Rapid Shutdown Equipment (PVRSE)

This product is UL Listed as PV Rapid Shut Down Equipment and conforms with NEC-2014 and NEC-2017 section 690.12 and C22.1-2018 Rule 64-220 Rapid Shutdown of PV Systems, for AC and DC conductors, when installed according to the following requirements:

- Microinverters and all DC connections must be installed inside the array boundary. **Enphase further requires that the microinverters and DC connections be installed under the PV module to avoid direct exposure to rain, UV, and other harmful weather events.**
- The array boundary is defined as 305 mm (1 ft.) from the array in all directions, or 1 m (3 ft.) from the point of entry inside a building.

This rapid shutdown system must be provided with an initiating device and (or with) status indicator which must be installed in a location accessible to first responders, or be connected to an automatic system which initiates rapid shutdown upon the activation of a system disconnect or activation of another type of emergency system.

The initiator shall be listed and identified as a disconnecting means that plainly indicates whether it is in the "off" or "on" position. Examples are:

- Service disconnecting means
- PV system disconnecting means
- Readily accessible switch or circuit breaker

The handle position of a switch or circuit breaker is suitable for use as an indicator. Refer to NEC or CSA C22.1-2018 for more information.

Additionally, in a prominent location near the initiator device, a placard or label must be provided with a permanent marking including the following wording: **'PHOTOVOLTAIC SYSTEM EQUIPPED WITH RAPID SHUTDOWN'** The term 'PHOTOVOLTAIC' may be replaced with 'PV'.

The placard, label, or directory shall be reflective, with all letters capitalized and having a minimum height of 9.5 mm (3/8 in.) in white on red background.

SAFETY

IMPORTANT SAFETY INSTRUCTIONS SAVE THIS INFORMATION.

This guide contains important instructions to follow during installation of the Enphase IQ 8D Microinverter.

	WARNING: Hot surface.
	WARNING: Refer to safety instructions.
	DANGER: Risk of electric shock.
	Refer to manual
	Double-Insulated

Safety Symbols

	DANGER: Indicates a hazardous situation, which if not avoided, will result in death or serious injury.
	WARNING: Indicates a situation where failure to follow instructions may be a safety hazard or cause equipment malfunction. Use extreme caution and follow instructions carefully.
	WARNING: Indicates a situation where failure to follow instructions may result in burn injury.
	NOTE: Indicates information particularly important for optimal system operation.

General Safety

	DANGER: Risk of electric shock. Do not use Enphase equipment in a manner not specified by the manufacturer. Doing so may cause death or injury to persons, or damage to equipment.
	DANGER: Risk of electric shock. Be aware that installation of this equipment includes risk of electric shock.
	DANGER: Risk of electric shock. The DC conductors of this photovoltaic system are ungrounded and may be energized.
	DANGER: Risk of electric shock. Always de-energize the AC branch circuit before servicing. Never disconnect the DC connectors under load.

General Safety, continued

	DANGER: Risk of electric shock. Risk of fire. Only use electrical system components approved for wet locations.
	DANGER: Risk of electric shock. Risk of fire. Only qualified personnel should troubleshoot, install, or replace Enphase Microinverters or the Enphase QD Cable and Accessories.
	DANGER: Risk of electric shock. Risk of fire. Ensure that all AC and DC wiring is correct and that none of the AC or DC wires are pinched or damaged. Ensure that all AC junction boxes are properly closed.
	DANGER: Risk of electric shock. Risk of fire. Do not exceed the maximum number of microinverters in an AC branch circuit as listed in this guide. You must protect each microinverter AC branch circuit with a 20A maximum breaker or fuse, as appropriate.
	DANGER: Risk of electric shock. Risk of fire. Only qualified personnel may connect the Enphase Microinverter to the utility grid.
	WARNING: Risk of equipment damage. Enphase male and female connectors must only be mated with the matching male/female connector.
	WARNING: Before installing or using the Enphase Microinverter, read all instructions and cautionary markings in the technical description, on the Enphase Microinverter System, and on the photovoltaic (PV) equipment.
	WARNING: Do not connect Enphase Microinverters to the grid or energize the AC circuit(s) until you have completed all of the installation procedures and have received prior approval from the electrical utility company.
	WARNING: When the PV array is exposed to light, DC voltage is supplied to the PCE.
	NOTE: To ensure optimal reliability and to meet warranty requirements, install the Enphase Microinverters and Enphase QD Cable according to the instructions in this guide.
	NOTE: Provide support for the Enphase QD Cable at least every 1.8 m (6 feet).
	NOTE: Perform all electrical installations in accordance with all applicable local electrical codes, such as the Canadian Electrical Code, Part 1 and NFPA 70 (NEC).
	NOTE: The AC and DC connectors on the cabling are rated as a disconnect only when used with an Enphase Microinverter.
	NOTE: Protection against lightning and resulting voltage surge must be in accordance with local standards.

Microinverter Safety

	DANGER: Risk of electric shock. Risk of fire. Do not attempt to repair the Enphase Microinverter; it contains no user-serviceable parts. If it fails, contact Enphase customer service to obtain an RMA (return merchandise authorization) number and start the replacement process. Tampering with or opening the Enphase Microinverter will void the warranty.
	DANGER: Risk of fire. The DC conductors of the PV module must be labeled "PV Wire" or "PV Cable" when paired with the Enphase Microinverter.
	WARNING: You must match the DC operating voltage range of the PV module with the allowable input voltage range of the Enphase Microinverter.
	WARNING: The maximum open circuit voltage of the PV module must not exceed the specified maximum input DC voltage of the Enphase Microinverter.
	WARNING: Risk of equipment damage. Install the microinverter under the PV module to avoid direct exposure to rain, UV, and other harmful weather events. Always install the microinverter bracket side up. Do not mount the microinverter upside down. Do not expose the AC or DC connectors (on the Enphase QD Cable connection, PV module, or the microinverter) to rain or condensation before mating the connectors.
	WARNING: Risk of equipment damage. The Enphase Microinverter is not protected from damage due to moisture trapped in cabling systems. Never mate microinverters to cables that have been left disconnected and exposed to wet conditions. This voids the Enphase warranty.

Microinverter Safety, continued

	WARNING: Risk of equipment damage. The Enphase Microinverter functions only with a standard, compatible PV module with appropriate fill-factor, voltage, and current ratings. Unsupported devices include smart PV modules, fuel cells, wind or water turbines, DC generators, and non-Enphase batteries, etc. These devices do not behave like standard PV modules, so operation and compliance is not guaranteed. These devices may also damage the Enphase Microinverter by exceeding its electrical rating, making the system potentially unsafe.
	WARNING: Risk of skin burn. The chassis of the Enphase Microinverter is the heat sink. Under normal operating conditions, the temperature could be 20°C above ambient, but under extreme conditions the microinverter can reach a temperature of 90°C. To reduce risk of burns, use caution when working with microinverters.
	NOTE: The Enphase Microinverter has field-adjustable voltage and frequency trip points that may need to be set, depending upon local requirements. Only an authorized installer with the permission and following requirements of the local electrical authorities should make adjustments.


Enphase QD Cable Safety

	DANGER: Risk of electric shock. Do not install the Enphase QD Cable terminator while power is connected.
	DANGER: Risk of electric shock. Risk of fire. When stripping the sheath from the Enphase QD Cable, make sure the conductors are not damaged. If the exposed wires are damaged, the system may not function properly.
	DANGER: Risk of electric shock. Risk of fire. Do not leave AC connectors on the Enphase QD Cable uncovered for an extended period. You must cover any unused connector with a sealing cap.
	DANGER: Risk of electric shock. Risk of fire. Make sure protective sealing caps have been installed on all unused AC connectors. Unused AC connectors are live when the system is energized.
	WARNING: Use the terminator only once. If you open the terminator following installation, the latching mechanism is destroyed. Do not reuse the terminator. If the latching mechanism is defective, do not use the terminator. Do not circumvent or manipulate the latching mechanism.
	WARNING: When installing the Enphase QD Cable, secure any loose cable to minimize tripping hazard.
	NOTE: When looping the Enphase QD Cable, do not form loops smaller than 12 cm (4.75 inches) in diameter.
	NOTE: If you need to remove a sealing cap, you must use the Enphase disconnect tool.
	NOTE: When installing the Enphase QD Cable and accessories, adhere to the following: <ul style="list-style-type: none"> • Do not expose the terminator or cable connections to directed, pressurized liquid (water jets, etc.). • Do not expose the terminator or cable connections to continuous immersion. • Do not expose the terminator or cable connections to continuous tension (e.g., tension due to pulling or bending the cable near the connection). • Use only the connectors and cables provided. • Do not allow contamination or debris in the connectors. • Use the terminator and cable connections only when all parts are present and intact. • Do not install or use in potentially explosive environments. • Do not allow the terminator to come into contact with open flame. • Fit the terminator using only the prescribed tools and in the prescribed manner. • Use the terminator to seal the conductor end of the Enphase QD Cable; no other method is allowed.

© 2021 Enphase Energy. All rights reserved. Enphase, the Enphase logo, Enphase IQ 8D, Enphase Installer Toolkit, Enphase Enlighten, Enphase IQ Commercial Envoy, and other trademarks or service names are the trademarks of Enphase Energy, Inc. Data subject to change. 03-09-2021.

↑ To Sheet / A la hoja de: _____

Panel Group/Grupo de los paneles: Azimuth/Azimet: Tilt/Inclinación: Sheet/Hoja _____ of/de _____		Customer/Ciente:			Installer/Instalador:			N S E W N S E O	
1	2	3	4	5	6	7	8	9	
A									
B									
C									
D									
E									
F									
G									
H									



↓ To Sheet / A la hoja de: _____

Scan completed map and upload it to Enphase. Click "Add a New System" at <https://enlighten.enphaseenergy.com>. Use this map to build the virtual array in Enlighten's Array Builder.

Escanee el mapa completo y cárguelo en Enphase. Haga clic en "Añadir nuevo sistema" en <https://enlighten.enphaseenergy.com>. Utilice este mapa para crear el conjunto de paneles virtual en el Creador de conjuntos de paneles de Enlighten.

Envoy Serial Number Label /
Número de serie de Envoy

↓ To Sheet / A la hoja de: _____

