

Installing Enphase CTs

Use this instruction with the Enphase IQ Gateway quick install guide to install Enphase Current Transformers (CTs). The IQ Gateway uses CTs for precision energy production and consumption metering. Read and follow all warnings and instructions in this document and in the quick install guide included with the IQ Gateway and available at enphase.com/support.

SAFETY

Safety and advisory symbols

NOTE: This indicates information particularly important for optimal		DANGER: This indicates a hazardous situation, which, if not avoided, will result in death or serious injury.
system operation. Follow instructions carefully.	\checkmark	NOTE: This indicates information particularly important for optimal system operation. Follow instructions carefully.

Safety instructions

	DANGER: To reduce the risk of electric shock, always open or disconnect circuit from the power distribution system (or service) of the building before installing or servicing current transformers.
	DANGER: Risk of electrocution! Do not install CTs when current is flowing in the sensed circuit. Always install CT wires in the terminal blocks before energizing the sensed circuit.
	DANGER: If equipment is used in a manner not specified by Enphase Energy, Inc., the protection provided by the equipment may be impaired.
	DANGER: Risk of electric shock. Be aware that installation of this equipment includes risk of electric shock. If you wire the IQ Gateway at the sub-board, always de-energize the sub-board before beginning.
	DANGER: Risk of electric shock. Risk of fire. Only qualified personnel should troubleshoot, install, or replace the CTs.
\checkmark	NOTE: Because of variances in switchboard design and main power feed, there may not always be enough space to install CTs.
\checkmark	NOTE: Do not install the CTs in a switchboard where they exceed 75% of the wiring space of any cross-sectional area within the equipment.
\checkmark	NOTE: Perform all electrical installations in accordance with all national and local electrical codes.
\checkmark	NOTE: Restrict installation of current transformers in an area where they would block ventilation openings or in an area of breaker arc venting.
\checkmark	NOTE: Secure current transformer and route conductors so that they do not directly contact live terminals or bus.

Revision history

REVISION	DATE	DESCRIPTION			
140-00090-05	February 2024	Editorial updates.			
Previous releases					

Specifications

SPECIFICATION	CT-200-SPLIT
Model number	U40002
Primary voltage, current, and	250 V, 200 A
frequency ratings	45-66 Hz
Secondary current (maximum)	80 mA
Overvoltage category	IV (service entrance)
Pollution degree	2
Indoor use	yes
Operating ambient temperature range	-40°C to 65°C
Relative humidity rating	95% non-condensing
External burden resistance	The IQ Gateway provides burden resistance of max 5 ohms and min 0.1 watts
External dimenions (mm)	60.5 × 50.8 × 35.3
Internal aperture dimensions (mm)	24.38 × 21.33

Installation and removal

The installation and removal steps are as follows. For more information, refer to the *IQ* Gateway quick install guide.

Preparation

A) If not already done, de-energize the home load panel and the PV system.

Install CTs

- A) Before running multiple CT wires through the conduit, use colored tape to mark each CT and the far ends of its wires. Use a different color for each CT so you can know which wires correspond to a given CT.
- B) Make sure that the primary circuit wire(s) are de-energized until you have secured the CT wires in the terminal blocks. Connect the white and blue wires as appropriate for your installation, as described in the quick install guide for the IQ Gateway model you are installing.
- C) Tighten all connections as described in the quick install guide for the IQ Gateway model you are installing.
- D) Open and clamp the CT on primary circuit wire(s) as needed. Make sure that the CT closes with a click.
- ✓ NOTE: Only run active conductors through each CT. Each CT can monitor multiple active conductors of a given phase.

Remove CTs

- A) Open and remove the CTs from all wires.
- B) Disconnect the white and blue wires from the terminal blocks.

© 2024 Enphase Energy. All rights reserved. Enphase, the e and CC logos, IQ, and certain other marks listed at <u>https://enphase.com/trademark-usage-guidelines</u> are trademarks of Enphase Energy, Inc. in the U.S. and other countries. Data subject to change. 2024-02-28



Enphase Support: https://enphase.com/contact/support